


MODEL: AF-815;AF-820


DIMENSION OF PUMP



| Model | DN | DA | A | B | C | D | E | F | G | H |
|--------|-----|-----|------|-----|-----|-----|-----|-----|-----|------|
| AF-815 | 200 | 290 | 1045 | 880 | 661 | 501 | 483 | 372 | 910 | 1032 |
| AF-820 | 200 | 290 | 1045 | 880 | 661 | 501 | 483 | 372 | 910 | 1032 |

N.W.L: Normal water level
M.W.L: Minimum water level

DIMENSION OF GRS



| Model | DN | A | B | C | D | E | F | G | I | J | K | M | O | P | W1 | W2 | H1 | H2 | H3 |
|--------|-----|------|-----|-----|-----|-----|-----|-----|----|-----|----|-----|-----|----|-----|-----|------|-----|-----|
| AF-815 | 200 | 1159 | 757 | 230 | 491 | 300 | 200 | 175 | 95 | 320 | 2" | 545 | 269 | 41 | 948 | 410 | 1070 | 176 | 305 |
| AF-820 | 200 | 1159 | 757 | 230 | 491 | 300 | 200 | 175 | 95 | 320 | 2" | 545 | 269 | 41 | 948 | 410 | 1070 | 176 | 305 |

Note: When AF-815;AF-820 used with GRS,the base foot needs to be dismantled.